

SUNSATION® FLOOR STAND ASSEMBLY

PLEASE NOTE: The unit can only be attached in a horizontal position. (See photo)

1. **TO ASSEMBLE YOUR STAND:** Your unit will ship with the legs of the stand base folded to the center pole. Pull these out to form the tripod support stand (see photo a) and tighten the screw at the bottom base so the legs are secure and the stand is stable

2. **LOOSEN THE ROTATING PIECE:** (when the stand is collapsed this piece will be towards the top of the stand (see photo b) and pull the top of the stand out to your desired height and tighten to hold in place.

3. **TO PUT YOUR SUNSATON ON THE STAND:** Lay your SunSation on a flat surface with the back of the unit (manufacture sticker) face up. Remove the black plastic plug next to the on/off switch. The best way to do this is to reach through the screw hole with a thin long wire/stick (an unbent paperclip works great) and pop the plastic plug out.

4. **REMOVE** the Tightening Knob at the top of the floor stand, and keep it nearby

5. **PLACE** your SunSation on the stand by sliding the top of the floor stand into the circle space you just on covered (where the plug was) and line up the stand and SunSation screw holes.

6. **SCREW** the Tightening Knob in through the screw holes and tighten till the SunSation is securely attached to the stand.

7. Wrap the SunSation chord around the stand.

STAND DIMENSIONS:

HEIGHT: Adjustable, from floor to tip of stand: Minimum 46" & Maximum 64"

FOOTPRINT: 21" from tip of each stabilizing leg to tip of next stabilizing leg, each leg is 11" long

SunSation must be attached horizontally

